



INVESTOR IN PEOPLE

PRIORITY DOCUMENT
SUBMITTED OR TRANSMITTED IN
COMPLIANCE WITH
RULE 17.1(a) OR (b)

The Patent Office
Concept House
Cardiff Road
Newport
South Wales
NP10 8QQ

REC'D 02 JUN 2004

WIPO

PCT


I, the undersigned, being an officer duly authorised in accordance with Section 74(1) and (4) of the Deregulation & Contracting Out Act 1994, to sign and issue certificates on behalf of the Comptroller-General, hereby certify that annexed hereto is a true copy of the documents as originally filed in connection with the patent application identified therein.

In accordance with the Patents (Companies Re-registration) Rules 1982, if a company named in this certificate and any accompanying documents has re-registered under the Companies Act 1980 with the same name as that with which it was registered immediately before re-registration save for the substitution as, or inclusion as, the last part of the name of the words "public limited company" or their equivalents in Welsh, references to the name of the company in this certificate and any accompanying documents shall be treated as references to the name with which it is so re-registered.

In accordance with the rules, the words "public limited company" may be replaced by p.l.c., plc, P.L.C. or PLC.


Re-registration under the Companies Act does not constitute a new legal entity but merely subjects the company to certain additional company law rules.

BEST AVAILABLE COPY



Signed

Dated 21 May 2004



30APR03 E80913-1 026047
P01/7700-000-0309900.9

1/77

Request for grant of a patent

(See the notes on the back of this form. You can also get an explanatory leaflet from the Patent Office to help you fill in this form)

The Patent Office

Cardiff Road
Newport
South Wales
NP10 8QQ

1. Your reference 0300110

2. Patent application number
(The Patent Office will fill in this part) 0309900.9

3. Full name, address and postcode of the or of each applicant (underline all surnames) 30 APR 2003

SMITHS GROUP PLC
765 FINCHLEY ROAD
LONDON
NW11 8DS

Patents ADP number (if you know it)

8032310001

If the applicant is a corporate body, give the country/state of its incorporation

GB

4. Title of the invention
IMS SYSTEMS

5. Name of your agent (if you have one) J. M. FLINT

"Address for service" in the United Kingdom to which all correspondence should be sent (including the postcode)

765 FINCHLEY ROAD
LONDON
NW11 8DS

Patents ADP number (if you know it)

1063304001

If you are declaring priority from one or more earlier patent applications, give the country and the date of filing of the or of each of these earlier applications and (if you know it) the or each application number

Country

Priority application number
(if you know it)

Date of filing
(day / month / year)

If this application is divided or otherwise derived from an earlier UK application, give the number and the filing date of the earlier application

Number of earlier application

Date of filing
(day / month / year)

Is a statement of inventorship and of right to grant of a patent required in support of this request? (Answer 'Yes' if:

YES

a) any applicant named in part 3 is not an inventor, or
b) there is an inventor who is not named as an applicant, or

c) any named applicant is a corporate body.
See note (d))

Patents Form 1/77

9. Enter the number of sheets for any of the following items you are filing with this form. Do not count copies of the same document

Continuation sheets of this form

Description 9

Claim(s) 8

Abstract

Drawing(s) 3 23

10. If you are also filing any of the following, state how many against each item.

Priority documents

Translations of priority documents

Statement of inventorship and right to grant of a patent (Patents Form 7/77)

Request for preliminary examination and search (Patents Form 9/77)

Request for substantive examination (Patents Form 10/77)

Any other documents (please specify)

11.

I/We request the grant of a patent on the basis of this application.

Signature

Date 28 APRIL 2003

12. Name and daytime telephone number of person to contact in the United Kingdom

J.M. FLINT

020 8457 8220

Warning

After an application for a patent has been filed, the Comptroller of the Patent Office will consider whether publication or communication of the invention should be prohibited or restricted under Section 22 of the Patents Act 1977. You will be informed if it is necessary to prohibit or restrict your invention in this way. Furthermore, if you live in the United Kingdom, Section 23 of the Patents Act 1977 stops you from applying for a patent abroad without first getting written permission from the Patent Office unless an application has been filed at least 6 weeks beforehand in the United Kingdom for a patent for the same invention and either no direction prohibiting publication or communication has been given, or any such direction has been revoked.

Notes

a) If you need help to fill in this form or you have any questions, please contact the Patent Office on 08459 500505.

b) Write your answers in capital letters using black ink or you may type them.

c) If there is not enough space for all the relevant details on any part of this form, please continue on a separate sheet of paper and write "see continuation sheet" in the relevant part(s). Any continuation sheet should be attached to this form.

d) If you have answered 'Yes' Patents Form 1/77 will need to be filed.

e) Once you have filled in the form you must remember to sign and date it.

f) For details of the fee and ways to pay please contact the Patent Office.

IMS SYSTEMS

This invention relates to IMS systems.

IMS systems are often used to detect substances such as explosives, drugs, blister and nerve agents or the like. An IMS system typically includes a detector cell to which a sample of air containing a suspected substance is supplied as a gas or vapour. The cell operates at atmospheric pressure and contains electrodes that are energized to produce a voltage gradient across the cell. Molecules in the sample of air are ionized, such as by means of a radioactive source or by corona discharge, and are admitted into the drift region of the cell by an electrostatic gate at one end. The ionized molecules drift to the opposite end of the cell at a speed dependent on the size of the molecule. By measuring the time of flight across the cell it is possible to identify the ion. Entry of ions into the drift region is usually controlled by a Bradbury Nielson gate. This consists of two sets of parallel electrically-conducting wires spaced from one another by gaps. The electric potential between the two sets of wires is switched between two different, discrete voltages so that the gate either allows ions to enter the drift region or prevents them.

It has been proposed in GB 2300296 that a temporal switching signature with ion admission of approximately 50% be applied to the gate and a Fourier transformation technique be used to obtain the ion mobility spectrum. We are not aware to date of any IMS system being sold that employs this technique. This may be because the effect of noise on the signal makes it difficult to achieve good results.

It is an object of the present invention to provide an alternative IMS system.

According to one aspect of the present invention there is provided an IMS system including an IMS cell having a drift region and an entry gate, the system including drive means for controlling switching of the gate, the drive means being arranged to control switching of the gate in a pseudo-random binary sequence.

The pseudo-random binary sequence input may be bit-flipped to reduce noise. The output is preferably analysed by matrix algebra. The system may be arranged to carry out deconvolution on the cell output using matrix algebra.

According to another aspect of the present invention there is provided a method of controlling switching of an admittance gate in an IMS system involving switching the gate in a pseudo-random binary sequence.

An IMS system according to the present invention, will now be described, by way of example, with reference to the accompanying drawings, in which:

Figure 1 is a schematic diagram of the system;

Figure 2 is a graph comparing a PRBS autocorrelation peak with a normal spectrum peak;

Figure 3 is a flow diagram of the PRBS operating mode;

Figure 4 is a flow diagram of the PRBS data analysis method;

Figure 5 is a graph of raw PRBS data for a full cycle pre-charge and for a 20ms pre-charge; and

Figure 6 is a graph comparing the normalised spectra of DPM in the PRBS and normal modes.

With reference first to Figure 1, the system includes an IMS drift cell 1 with an ion admittance gate 3, a drift region 4 and an ion receiving head 5. The gate 3 includes drive electronics and a power supply capable of functioning at relatively high duty cycle modulation rates. The cell 1 has an input 6 for controlling operation of the gate 3, and an output 7 for the amplified output of the receiving head 5. A computer 10 receives on line 11 the output from the head amplifier and also supplies control signals via line 12 to the gate control input 6. The computer 10 performs an analysis on the input signals to provide an ion mobility spectrum output to a display, alarm or other utilisation means 13.

The computer 10 controls switching of the gate 3 by switching it on (1) to enable admission of ions to the drift chamber 4, or switching it off (0) to prevent flow of ions. The series of 1s and 0s follows a pseudo random binary sequence (PRBS). The preferred PRBS is a "maximal length sequence", which is readily generated using linear feedback shift registers or in software. Alternatively, the PRBS could be a "quadratic residue sequence".

The PRBS modulated output from the cell 1 can be analysed in two different ways. The data can be analysed in the frequency domain with Fourier Transform techniques or it can be analysed directly in the time domain using matrix algebra. Both techniques have been found to give similar results but the matrix algebra technique is preferred because it requires less computation power.

The matrix algebra technique involves constructing a square analyser matrix S , with the same dimension as the input data column matrix D , in which the top row is the applied PRBS. Each successive row of S is formed by taking the previous row, shifting it one place to the right and wrapping the end back onto the beginning. The output spectrum Z expressed as a column matrix is obtained from the input matrix D by simple matrix multiplication:

$$Z = S \cdot D$$

The PRBS modulation enables multiple pulses to be averaged in significantly less time than would be required to average multiple single shots. A PRBS of length n would be expected to give an improvement in signal-to-noise ratio of $\sqrt{n}/\sqrt{2}$ over single shot data collection using the same pulse length, given that a sequence of length n effectively contains $n/2$ pulses.

If the 0s in the original PRBS were replaced with -1 s then, for the corresponding sequence of 1s and -1 s, the associated improvement in signal-to-noise ratio would be \sqrt{n} .

Such a sequence cannot be achieved directly in an IMS system because there is no way to reverse ion flow. It can, however, be achieved by combining two appropriate sequences.

For example, if S and S_β are the analysing matrices corresponding to the original and bit-flipped PRBSs respectively, D and D_β are the corresponding data sets obtained from the system for each modulation set and N is the superimposed set of systematic noise data, assumed to be the same for each modulation sequence, then the following identities can readily be verified:

$$D_\beta = I_c - D$$

$$S_\beta = I_s - S$$

where I_c and I_s are unit matrices of appropriate dimensions and, in the presence of systematic noise represented by column matrix N , the following four analysis sets can be defined:

$$Z_{11} = S.(D + N)$$

$$Z_{1\beta} = S.(D_\beta + N)$$

$$Z_{\beta 1} = S_\beta.(D + N)$$

$$Z_{\beta\beta} = S_\beta.(D_\beta + N)$$

These can be combined to give:

$$\begin{aligned} Z &= Z_{11} + Z_{\beta\beta} - Z_{1\beta} - Z_{\beta 1} \\ &= S.(D+N) + S.(D_\beta + N) - S.(D_\beta + N) - S_\beta.(D + N) \\ &= (S - S_\beta).(D + N) - (S - S_\beta).(D_\beta + N) \\ &= (S - I_s + S).(D + N - I_c + D - N) \end{aligned}$$

$$= (2S - I_s)(2D - I_c)$$

$$= 4S.D + \text{const}$$

this has an autocorrelation peak of height N (sequence length N) with a baseline of -1 , thus removing systematic noise from the processed spectrum.

The PRBS modulation provides improved resolution over single shot data collection methods for several reasons. First, the shorter gate opening times give improved resolution with a more precisely defined packet of ions. The width of the sequence autocorrelation peak is equal to the narrowest pulse in the sequence. To minimize electronic noise in the system, the system frequency response is matched to the frequency spectrum of the detected pulses. Shorter pulses require higher bandwidths leading to inherently more electronic noise. For fixed ion currents, shorter pulses with matching system bandwidths result in improved resolution but with a reduced signal-to-noise ratio. If the bandwidth of the system is reduced to reduce the noise, the detected pulse will be spread and reduced in amplitude. This negates the improved resolution.

Fourier analysis, however, shows that a long sequence of shorter pulses does not impose additional bandwidth requirements on the electronics of the system so higher resolutions can be achieved without any reduction in the signal-to-noise ratio. This is illustrated in Figure 2 where the spectrum of a single pulse is indicated by the curve marked SP and that of a PRBS system is indicated by the curve marked PRBS using a conventional receiving head amplifier and filters. The single pulse has a width of $80\mu\text{s}$ and the PRBS signal has a length of 2047 and a bit width of $80\mu\text{s}$. It can be seen that the PRBS has a significantly better resolution.

The computer 10 is preferably also arranged to carry out deconvolution in order to enhance resolution. It is well known that this can be carried out in the frequency domain but it is also possible directly in the time domain using matrix algebra.

If P is the column matrix representing the observed spectrum and $P1$ is the column matrix representing the un-spread spectrum then:

$$P = A.P1$$

where A is a square matrix comprising the spreading function.

In practice, A is a wrapped matrix like the PRBS analysing matrix where each row is the same as the one above but moved one place to the right and wrapped back on itself.

Therefore:

$$A^{-1}.P = A^{-1}.A.P1 = P1$$

where A^{-1} is the inverse of the matrix A , also a wrapped matrix.

The computer performs deconvolution on the observed spectrum from knowledge of the spreading function, which is used to form a wrapped square matrix, and which is then inverted.

Figures 3 and 4 are flow diagrams illustrating the main processes involved in obtaining spectra using PRBS modulation. The upper two boxes in Figure 3 show the reading of the chosen PRBS from a data file and its use together with additional parameters entered by the user, such as bit width, to generate the output waveform. This output is then applied to

the gate 3 and the resulting signal from the head amplifiers 5 are then recorded by the computer 10. The collected data is then pre-processed, if required, such as by subtracting one data set from another, before being analysed. Details of the analysis activity are shown in Figure 4, the collected data from the head amplifiers 5 as a column vector is multiplied with the PRBS as a row vector to produce a single data point in the output spectrum. The PRBS is then "bit shifted" and "wrapped" one place and the process repeated to generate the remaining points in the output spectrum.

The PRBS technique is essentially continuous, the sequence repeating when it reaches its end point. For this reason, it is pre-charged with the final 20ms of the PRBS to get the ions and data into the system before beginning the analysis. Typically, the system is allowed to run through the entire PRBS twice and only the repeated sequence is analysed.

Figure 5 shows typical raw data collected from a PRBS-modulated IMS cell using a PRBS of length 2047 and a bit length of 40 μ s, giving a total time of just over 80ms. The broken line shows the end of one full cycle followed by the start of a second. The solid line trace consists of the final 20ms of the PRBS appended to the front of it to pre-charge the part of the spectrum of interest.

Figure 6 shows the normalized spectra for the substance DPM (dipropylene glycol monomethyl ether) produced using conventional averaged single-pulse techniques, as shown by the trace labelled "SP", and using PRBS techniques, as shown by the trace labelled "PRBS". It can be seen that the spectrum produced by the PRBS technique produces a noticeably higher amplitude for two of the three main peaks.

The present invention can be used to enable IMS systems to be provided with improved signal-to-noise and enhanced resolutions compared with conventional techniques.

[Y:\PATENTS\SPEC03\prims.doc]




FIG. 1




FIG. 2




FIG. 3




FIG. 4

313




FIG. 5

Normalised PRBS Spectrum





FIG. 6

THE PATENT OFFICE
24 MAY 2004
Received in Patents
International Unit

PCT/GB2004/001816



This Page is inserted by IFW Indexing and Scanning
Operations and is not part of the Official Record

BEST AVAILABLE IMAGES

Defective images within this document are accurate representations of the original documents submitted by the applicant.

Defects in the images include but are not limited to the items checked:

- ☐ BLACK BORDERS
- ☐ IMAGE CUT OFF AT TOP, BOTTOM OR SIDES
- ☐ FADED TEXT OR DRAWING
- ☐ BLURED OR ILLEGIBLE TEXT OR DRAWING
- ☐ SKEWED/SLANTED IMAGES
- ☐ COLORED OR BLACK AND WHITE PHOTOGRAPHS
- ☐ GRAY SCALE DOCUMENTS
- ☐ LINES OR MARKS ON ORIGINAL DOCUMENT
- ☐ REPERENCE(S) OR EXHIBIT(S) SUBMITTED ARE POOR QUALITY
- ☐ OTHER: _____

IMAGES ARE BEST AVAILABLE COPY.

**As rescanning documents *will not* correct images
problems checked, please do not report the
problems to the IFW Image Problem Mailbox**